



WYMV.E122717

Telemetering Equipment for Use in Hazardous Locations

See General Information for Telemetering Equipment for Use in Hazardous Locations

FLOWSERVE CORP

E122717

FLOW CONTROL DIV

UTAH OPERATION

1350 N MOUNTAIN SPRINGS PKY

SPRINGVILLE, UT 84663 USA

Rotary monitor "Ultra Switch" for use in Class I, Groups A, B, C and D; Class II, Groups E, F and G hazardous locations.

Series Cat. No. ASL followed by B4, BK, BL, G1, G2, P1, P2, PK, PL or PP, followed by O or H, followed by alphanumeric characters.

Rotary monitor "Aviator" for use in Class I, Groups C and D; Class II, Groups E, F and G hazardous locations.

Cat. No. X followed by V, followed by a single alphanumeric digit, followed by B4, BK, BL, BM, M1, MG, P1, P2, PK, PL, PM, PP, R1 or R4, followed by 0, followed by A, C, F, G, H, J, K or P, followed by three alphanumeric digits. May have one or two digit alpha-numeric prefix.

Rotary monitors "Buswitch" and "Ultra Switch" for use in Class I, Groups C and D; Class II, Groups E, F and G hazardous locations.

Series Cat. No. ASL followed by B4, BK, BL, G1, G2, P1, P2, PK, PL or PP, followed by alphanumeric characters, followed by 0 or H, followed by alphanumeric characters.

Cat. No. X followed by V, followed by a single alphanumeric digit, followed by F2, F4 or FD, followed by 0 or 2, followed by 0, G, J or P, followed by three alphanumeric digits. May have one or two digit alpha-numeric prefix.

Rotary monitor "Ultra Switch" for use in Class I, Groups C and D; Class II, Groups E, F and G hazardous locations.

Cat. Nos. S, N, G or M followed by XCL, followed by a single alpha-numeric character; followed by 0, 1, 2, 3, or 4, followed by 00, M1, MA, MC, MG, M3, MB, P4, P5, PE, PP, PL, PT, PX, N8, NQ, NR, NS, NT, NP, NJ, NU, SN or FZ, may be followed by 00, 01, 02, 03, m1, m2, m3 or M4, may be

followed by 0, T, D, E, S, A, B, or C, may be followed by a single alpha-numeric character, may be followed by a single alpha numeric character. May have a one or two digit alpha-numeric prefix.

Rotary monitor "Aviator" for use in Class I, Groups A, B, C and D, Division 2; Class II, Groups F and G, Division 2 hazardous locations.

Cat. No. X followed by V, followed by a single alphanumeric digit, followed by B4, BK, BL, BM, P1, P2, PK, PL, PM, PP, R1 or R4, followed by 0, followed by A, C, F, G, H, J, K or P, followed by three alphanumeric digits. May have one or two digit alpha-numeric prefix.

Rotary monitor "Buswitch" and "Ultra Switch" for use in Class I, Groups A, B, C and D, Division 2; Class II, Groups F and G, Division 2 hazardous locations.

Cat. No. X followed by V, followed by a single alphanumeric digit, followed by F2, F4 or FD, followed by 0 or 2, followed by 0, G, J or P, followed by three alphanumeric digits. May have one or two digit alpha-numeric prefix.

Cat. Nos. S, N, G or M followed by XCL, followed by a single alpha-numeric character, followed by 0, 1, 2, 3, or 4, followed by 00, M1, MA, MC, MG, M3, MB, P4, P5, PE, PP, PL, PT, PX, N8, NQ, NR, NS, NT, NP, NJ, NU, SN or FZ, may be followed by 00, 01, 02, 03, m1, m2, m3 or M4, may be followed by 0, T, D, E, S, A, B, or C, may be followed by a single alpha-numeric character, may be followed by a single alpha numeric character. May have a one or two digit alpha-numeric prefix.

Rotary monitor "Ultra Switch" for use in Class I, Groups A, B, C and D, Division 2; Class II, Groups F and G, Division 2 hazardous locations.

Series Cat. No. ASL followed by B4, BK, BL, G1, G2, P1, P2, PK, PL or PP, followed by O or H, followed by alphanumeric characters.

Rotary monitor "Ultra Switch" for use in Class I, Groups C and D, Division 2; Class II, Groups F and G, Division 2 hazardous locations.

Series Cat. No. ASL followed by B4, BK, BL, G1, G2, P1, P2, PK, PL or PP, followed by alphanumeric characters, followed by 0 or H, followed by alphanumeric characters.

Rotary monitor "Ultra Switch" for use in Class I, Groups A, B, C and D, Division 2; Class II, Groups F and G, Division 2 hazardous locations.

Cat. No. PL followed by a single alphanumeric character, followed by 4, 5, 6, E, F, H, L, M, P, R, T, U, W, X or Y, followed by 0, followed by 0, B, C, E, F, G, H, J or K, followed by 0, H or P, may be followed by 3, 4, 5, 6, 7, 8, 9, A, B, C, D or E, may be followed by one or two alpha-numeric characters, may have a two digit alpha-numeric prefix. Cat. No. DNF followed by two alphanumeric characters, followed by E, F, P or T, followed by 0 or 1, followed by alphanumeric characters.

Cat. No. GL followed by a single alphanumeric character, followed by 4, 5, 6, E, F, L, P, T or X, followed by A, B, C, E, F, G, H, J, K or 0, may be followed by H or T, followed by 3, 4, 5, 6, 7, 8, 9, A, B, C, D or E. May have prefix A or F, followed by B, D, E, H or N. Cat. No. DNF followed by two alphanumeric characters, followed by E, F, P or T, followed by 0 or 1, followed by alphanumeric characters.

Last Updated on 2004-10-13

This page and all contents are Copyright © 2005 by Underwriters Laboratories Inc.®

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright © 2005 Underwriters Laboratories Inc.®"

An independent organization working for a safer world with integrity, precision and knowledge.

